



Poz.	Číslo	Počet	Popis
1	DE920-3G	2	DSP rezistor 100 Ohm
2	DE920-3M	2	DSP rezistor 500 Ohm
3	DE920-3O	1	DSP rezistor 1 kOhm
4	DE920-3R	1	DSP rezistor 10 kOhm
5	DE920-3S	1	DSP potenciometer 470 Ohm
6	DE920-3T	1	DSP otočný odpor 10 kOhm
7	DE927-1M	1	DSP motorček s prevodovkou
8	DE920-2K	3	DSP batéria 1,5 V
9	DE920-2B	1	DSP dútnavka
10	DE922-1L	1	DSP pre cievku, prívod zľava
11	DE922-1B	1	DSP pre cievku s odbočkou v strede
12	DE922-1A	1	DSP pre cievku
13	DE920-2S	1	DSP tlačítko
14	DE920-2R	3	DSP vypínač ON/OFF
15	DE920-2T	2	DSP prepínač
16	DE920-2A	2	DSP objímka E 10
17	DE920-2F	3	DSP objímka E 14
18	DE920-2L	2	DSP upínacia zdierka
19	DE920-2M	1	DSP upínač pre tyče, D= 10 mm

Uloženie:

- | | | | |
|----|----------|---|--------------------------------|
| 20 | P7910-1A | 1 | Plastová vložka E/EL DZS |
| 21 | P7806-1G | 1 | Úložný box II, veľký, s krytom |

Plán rozloženia a 2 samolepky

20

21